

Please Read and Save this Use and Care Book.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before using.
- To protect against risk of electrical shock do not immerse cord, plugs or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contacting moving parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or is dropped or damaged in any manner. Return appliance to the nearest authorized service facility or call the appropriate toll-free number on the front of this manual for examination, repair or electrical or mechanical adjustment. Or, call the appropriate toll-free number on the cover of this manual.
- The use of attachments, including canning jars, not recommended by the manufacturer may cause fire, electric shock or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter.
- Keep hands and utensils out of container while blending to reduce the risk of severe injury to persons or damage to the blender. A scraper may be used, but must be used only when the blender is not running.
- Blades are sharp. Handle carefully.
- To reduce the risk of injury, never place cutter-assembly blades on base without jar properly attached.
- Always operate blender with cover in place.
- When blending hot liquids, remove center piece of two-piece cover.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

- 6. For blending tasks such as grinding coffee beans or nuts, press PULSE button for no more than 5 seconds at a time. Release and allow blades to stop turning. Repeat until food has desired consistency. Releasing the PULSE button automatically turns the blender off.
 - 7. To add ingredients while the blender is running, open the lid cap and drop ingredients through the opening.
- Important: Do not remove the lid while the blender is running.**
- 8. When finished, press the OFF button. Make sure blades have completely stopped before attempting to remove the blending jar from the base.
 - 9. To remove the jar after blending is complete, grasp the handle and lift the jar straight up.
- Important: Never replace the jar while motor is running.**
- 10. Remove the lid to pour.
 - 11. Always unplug the appliance when not in use.

INTELLIGENT FUSE® OVERHEAT PROTECTION SYSTEM

This blender has a motor heat protection system that will automatically shut off the blender when the motor is overloaded or if the blender has been running too long with a heavy load.

If this happens, unplug the blender and wait 15-20 minutes to allow the motor to cool down. Plug in the blender and resume blending.

BLENDING TIPS AND TECHNIQUES

- Cut food into pieces no larger than ¾-inch for use in the blender.
- When preparing foods that have several different kinds of ingredients, always add liquid ingredients first.
- When ingredients splatter onto the sides of the jar or the mixture is very thick, press the OFF button to turn appliance off. Remove the lid and use a rubber spatula to scrape down the sides of the jar and to redistribute the food pushing food toward the blades. Replace the lid and continue blending.
- **Appliance should always have cover in place when in use.**
- **Do not place blending jar on base when motor is running.**
- The lid cap holds up to 2 oz. liquid and can be used as a measure and when adding ingredients such as juices, milk, cream and liquor.
- When making bread crumbs, chopping nuts or grinding coffee beans make sure blending jar is completely dry.
- When using PULSE function use short bursts. Allow the blades to stop rotating between pulses. Do not use pulse for more than 1½ minutes.
- Use the PULSE button to begin the blending process when preparing beverages that include ice cubes; this helps to produce a smoother texture.
- The PULSE function is helpful when short bursts of power are needed such as when preparing thick smoothies or milkshakes, chopping nuts or grinding coffee beans.
- It is helpful to begin the blending process on the lowest speed and then increase to a higher speed, if necessary.
- To stop blending, press the OFF button at any time.
- When blending hot ingredients always let them cool at least 5 minutes before blending. Before beginning to blend, remove the lid cap and put it back with the opened side tilted away from you. Cover lid with a cloth to avoid splattering and only use lowest speed. Do not blend more than 2½ to 3 cups at a time.

- Children should be supervised to ensure that they do not play with the appliance.

SAVE THESE INSTRUCTIONS.

This product is for household use only.

POLARIZED PLUG (120V Models Only)

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

TAMPER-RESISTANT SCREW

Warning: This appliance is equipped with a tamper-resistant screw to prevent removal of the outer cover. To reduce the risk of fire or electric shock, do not attempt to remove the outer cover. There are no user-serviceable parts inside. Repair should be done only by authorized service personnel.

ELECTRICAL CORD

- a) A short power-supply cord (or detachable power-supply cord) is to be provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord.
- b) Longer detachable power-supply cords or extension cords are available and may be used if care is exercised in their use.
- c) If a long detachable power-supply cord or extension cord is used,
 - 1) The marked electrical rating of the detachable power-supply cord or extension cord should be at least as great as the electrical rating of the appliance,
 - 2) If the appliance is of the grounded type, the extension cord should be a grounding-type 3-wire cord, and
 - 3) The longer cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over.

Note: If the power supply cord is damaged, it should be replaced by qualified personnel; in Latin America, by an authorized service center.

Care and Cleaning

This product contains no user serviceable parts. Refer service to qualified service personnel.

CLEANING

- 1. Before cleaning, turn off and unplug appliance.
 - 2. Lift blending jar by handle off power base.
 - 3. Remove gasket and blade assembly.
- Caution: Blades are sharp, handle carefully.**
- 4. Remove lid and lid cap.
 - 5. Wash removable parts by hand or in your dishwasher. Place jar on bottom rack and rest of parts on top-rack only.

QUICK CLEANING

For quick cleanup, combine 1 cup hot water and a drop of liquid dish soap in the blending jar. Cover and blend on CLEAN for about 30 seconds. Discard liquid and rinse jar thoroughly.

Important:

- **Do not place jar parts in boiling liquids.**
- **Do not immerse base in liquid. Wipe base with damp cloth and dry thoroughly.**
- **Remove stubborn spots by rubbing with damp cloth and nonabrasive cleaner.**

Note: If liquids spill onto base, wipe with damp cloth and dry thoroughly. Do not use rough scouring pads or cleansers on parts or finish.

NEED HELP?

For service, repair or any questions regarding your appliance, call the appropriate 800 number on cover of this book. Please **DO NOT** return the product to the place of purchase. Also, please **DO NOT** mail product back to manufacturer, nor bring it to a service center. You may also want to consult the website listed on the cover of this manual.

TWO-YEAR LIMITED WARRANTY (Applies only in the United States and Canada)

What does it cover?

- Any defect in material or workmanship provided; however, Applica’s liability will not exceed the purchase price of product.

For how long?

- Two years from the date of original purchase with proof of such purchase.

What will we do to help you?

- Provide you with a reasonably similar replacement product that is either new or factory refurbished.

How do you get service?

- Save your receipt as proof of date of sale.

- Visit the online service website at www.prodprotect.com/applica, or call toll-free 1-800-231-9786, for general warranty service.
- If you need parts or accessories, please call 1-800-738-0245.

What does your warranty not cover?

- Damage from commercial use
 - Damage from misuse, abuse or neglect
 - Products that have been modified in any way
 - Products used or serviced outside the country of purchase
 - Glass parts and other accessory items that are packed with the unit
 - Shipping and handling costs associated with the replacement of the unit
 - Consequential or incidental damages (Please note, however, that some states do not allow the exclusion or limitation of consequential or incidental damages, so this limitation may not apply to you.)
- How does state law relate to this warranty?**
- This warranty gives you specific legal rights. You may also have other rights that vary from state to state or province to province.

Product may vary slightly from what is illustrated.



- 1. Lid cap
- 2. Lid
- 3. Perfect Pour™ blending jar [48 oz. / 1500 ml]
- 4. Handle
- 5. Blade assembly
- 6. Gasket
- 7. Jar base
- 8. Stability interlock system
- 9. Blender base
- 10. Control panel

¿NECESITA AYUDA?

Para servicio, reparaciones o preguntas relacionadas al producto, por favor llame al número del centro de servicio que se indica para el país donde usted compró su producto.

NO devuélva el producto al fabricante. Llame o lleve el producto a un centro de servicio autorizado.

DOS AÑOS DE GARANTÍA LIMITADA (No aplica en México, Estados Unidos y Canadá)

- **¿Qué cubre la garantía?** La garantía cubre cualquier defecto de materiales o de mano de obra que no haya sido generado por el uso incorrecto del producto.

¿Por cuánto tiempo es válida la garantía?

- Por dos años a partir de la fecha original de compra mientras que tenga una prueba de la compra.
- **¿Cómo se obtiene el servicio necesario?** Conserve el recibo original como comprobante de la fecha de compra, comuníquese con el centro de servicio de su país y haga efectiva su garantía si cumple lo indicado en el manual de instrucciones.

¿Cómo se puede obtener servicio?

- Conserve el recibo original de compra.
- Por favor llame al número del centro de servicio autorizado.

¿Qué aspectos no cubre esta garantía?

- Los productos que han sido utilizados en condiciones distintas a las normales.
- Los daños ocasionados por el mal uso, el abuso o negligencia.
- Los productos que han sido alterados de alguna manera.
- Los daños ocasionados por el uso comercial del producto.
- Los productos utilizados o reparados fuera del país original de compra.
- Las piezas de vidrio y demás accesorios empacados con el aparato.
- Los gastos de tramitación y embarque asociados al reemplazo del producto.
- Los daños y perjuicios indirectos o incidentales.

¿Qué relación tiene la ley estatal con esta garantía?

- Esta garantía le otorga derechos legales específicos y el consumidor podría tener otros derechos que varían de una región a otra.

Póliza de Garantía

(Válida sólo para México)

Duración

Rayovac de México SA de CV garantiza este producto por 2 años a partir de la fecha original de compra.

¿Qué cubre esta garantía?

Esta Garantía cubre cualquier defecto que presenten las piezas, componentes y la mano de obra contenidas en este producto.

Requisitos para hacer válida la garantía

Para reclamar su Garantía deberá presentar al Centro de Servicio Autorizado la póliza sellada por el establecimiento en donde adquirió el producto. Si no la tiene, podrá presentar el comprobante de compra original.

¿Donde hago válida la garantía?

Llame sin costo al teléfono 01 800 714 2503, para ubicar el Centro de Servicio Autorizado más cercano a su domicilio en donde usted podrá encontrar partes, componentes, consumibles y accesorios.

Procedimiento para hacer válida la garantía

Acuda al Centro de Servicio Autorizado con el producto con la póliza de Garantía sellada o el comprobante de compra original, ahí se reemplazará cualquier pieza o componente defectuoso sin cargo alguno para el usuario final. Esta Garantía incluye los gastos de transportación que se deriven de su cumplimiento.

Excepciones

Esta Garantía no será válida cuando el producto:

- A) Se hubiese utilizado en condiciones distintas a las normales.
- B) No hubiese sido operado de acuerdo con el instructivo de uso que le acompaña.
- C) Cuando el producto hubiese sido alterado o reparado por personas no autorizadas por Rayovac de México SA de CV.

Nota: Usted podrá encontrar partes, componentes, consumibles y accesorios en los centros de servicios autorizados. Esta garantía incluyen los gastos de transportación que se deriven de sus cumplimiento dentro de sus red de servicio.

How to Use


This product is for household use only.

GETTING STARTED


- Remove all packing material and any stickers from the product.
- Remove and save literature.
- Please go to www.prodprotect.com/applica to register your warranty.
- Wash all removable parts as instructed in CARE AND CLEANING section of this manual.
- Wipe outside of appliance with a damp cloth; dry thoroughly.

BLENDER JAR ASSEMBLY

- 1. Turn blending jar upside down and place flat on countertop or work surface.
- 2. Put the gasket on top of the blade assembly.
- 3. Place blade assembly with gasket in bottom opening of the jar with blades facing down.



- 4. Place jar base onto jar and rotate clockwise until it is tight **(A)**.
- 5. Turn assembled jar right side up.
- 6. Place lid with lid cap on blending jar.
- 7. Uncoil power cord from storage area under the base.



- 8. Place jar on blender base so that notches on the jar align with the notches on the base and black plastic housing is no longer visible. Make sure jar is securely attached to the base **(B)**.
- 9. Blender is now ready for use.

BLENDING

- 1. Place foods to be blended into blending jar.
- 2. Place lid on jar; make sure lid cap is in place.
- 3. Plug power cord into standard electrical outlet.

Important: If the power indicator light is flashing when the appliance is plugged in, unplug the appliance, wait 30 seconds, then plug in again. If the light is still flashing, discontinue use and contact Consumer Services for assistance.

Important: If appliance runs for more than 2 consecutive minutes, the motor will shut off. If this occurs, press any speed button to resume operation.

Note: When in use, do not leave blender unattended. When using hard foods, such as ice, cheese, nuts and coffee beans, keep one hand on the lid to keep blender in place.

- 4. Press button to select the speed that best suits your desired task).

Note: It is always helpful to start with a low speed and increase speed to match desired blending operation.

- 5. When blending thick mixtures, such as smoothies, power drinks and milkshakes press the PULSE button several times to begin the blending process. Press the PULSE button for no more than 5 seconds at a time. This helps break up the ice

Por favor llame al número correspondiente que aparece en la lista a continuación para solicitar que se haga efectiva la garantía y donde Ud. puede solicitar servicio, reparaciones o partes en el país donde el producto fué comprado.	
Argentina Servicio Técnico Monroe 3351 CABA Argentina Tel: 0800 – 444 - 7296 servicios@rayovac.com.ar	México Artículo 123 # 95 Local 109 y 112 Col. Centro, Cuauhtemoc, México, D.F. Tel. 01 800 714 2503
Chile SERVICIO DE MAQUINAS Y HERRAMIENTAS LTDA. Portugal N° 644 Santiago – Chile Fonos: 02-6355208 / 02-6341169 Email: servicio@spectrumbrands.cl Call center: 800-171-051	Nicaragua ServiTotal De semáforo de portezuelo 500 metros al sur. Managua, Nicaragua, Tel. (505) 248-7001
Colombia PLINARES Avenida Quito # 88A-09 Bogotá, Colombia Tel. sin costo 01 800 7001870	Panamá Servicios Técnicos CAPRI Tumbamuerto Boulevard El Dorado Panamá 500 metros al sur. Tel. 3020-480-800 sin costo (507) 2360-236 / 159
Costa Rica Aplicaciones Electromecanicas, S.A. Calle 26 Bis y Ave. 3 San Jose, Costa Rica Tel.: (506) 257-5716 / 223-0136	Perú Servicio Central Fast Service Av. Angamos Este 2431 San Borja, Lima Perú Tel. (511) 2251 388
Ecuador Servicio Master de Ecuador Av. 6 de Diciembre 9276 y los Alamos Tel. (593) 2281-3882	Puerto Rico Buckeye Service Jesús P. Piñero #1013 Puerto Nuevo, SJ PR 00920 Tel.: (787) 782-6175
El Salvador Calle San Antonio Abad 2936 San Salvador, El Salvador Tel. (503) 2284-8374	Republica Dominicana Plaza Lama, S.A. Av. Duarte #94 Santo Domingo, República Dominicana Tel.: (809) 687-9171
Guatemala MacPartes SA 3ª Calle 414 Zona 9 Frente a Tecun Tel. (502) 2331-5020 / 2332-2101	Venezuela Inversiones BDR CA Av. Casanova C.C. City Market Nivel Plaza Local 153 Diagonal Hotel Melia, Caracas. Tel. (582) 324-0969
Honduras ServiTotal Contigua a Telecentro Tegucigalpa, Honduras, Tel. (504) 235-6271	www.applicaservice.com servicio@applicamail.com