

Juiceman®



COMPACT

juicer

JM250

Instruction Booklet



THANK YOU

FOR YOUR PURCHASE!



YouTube



SHARE YOUR PICTURES & STORIES WITH US ONLINE



REGISTER ONLINE AT :

www.prodprotect.com/applica



RATE & REVIEW YOUR PRODUCT

www.juiceman.com

Should you have any questions or concerns with your new product, please call our Customer Service Line at 1-800-231-9786 (US and Canada).
Please do not return to the store.

Please Read and Save this Use and Care Book.

IMPORTANT SAFEGUARDS

All Juiceman products are designed with your safety in mind. When using electrical appliances, basic safety precautions should always be adhered to, including the following:

Read all instructions and save for future reference:

- Remove any stickers before using the juice extractor.
- To protect against the risk of electrical shock, do not immerse cord, plug or base unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from the outlet when not in use, before putting on or taking off parts and before cleaning.
- Always make sure the juicer is properly assembled before plugging in and using.
- Avoid contacting moving parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Contact the consumer service number listed in this manual.
- The use of accessories or attachments not recommended or sold by the manufacturer may cause fire, electric shock or injury.
- Do not use outdoors.
- Do not let cord hang over edge of the table or counter.
- Do not let cord touch hot surfaces or become knotted.
- Do not leave the appliance unattended when in use.
- Always make sure juicer cover is clamped securely in place before motor is turned on. Do not unfasten clamps while juicer is in operation.
- Be sure to turn dial to OFF position after each use of your juicer. Make sure the motor stops completely before disassembling.
- Do not put your fingers or other objects into juicer opening while it is in operation. If food becomes lodged in opening, use food pusher or other piece of fruit or vegetable to push it down. When this method is not possible, turn the motor off and disassemble juicer to remove the remaining food.
- Do not use this appliance if the rotating sieve is damaged.
- Do not operate the juice extractor without pulp container in place.
- Keep the appliance clean; refer to care and cleaning section of this manual.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

SAVE THESE INSTRUCTIONS

Safety Features

This product is for household use only.

POLARIZED PLUG (120V MODELS ONLY)

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

TAMPER-RESISTANT SCREW

Warning: This appliance is equipped with a tamper-resistant screw to prevent removal of the outer cover. To reduce the risk of fire or electric shock, do not attempt to remove the outer cover. There are no user-serviceable parts inside. Repair should be done only by authorized service personnel.

ELECTRICAL CORD

- 1) A short power-supply cord is provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord.
- 2) If a long detachable power-supply cord or extension cord is used,
 - a) The marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance,
 - b) If the appliance is of the grounded type, the extension cord should be a grounding-type 3-wire cord, and
 - c) The longer cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over unintentionally.

Note: If the power cord is damaged, please contact the warranty department listed in these instructions.

Meet your **COMPACT** juicer

Compact but powerful, this juice extractor is easy to use and perfect for all levels of users!

Product may vary slightly from what is illustrated.



- | | |
|---|--|
| 1. Dual Food pushers (Part # 770293) | 7. Safety locking latch (on each side) Part #081343FL-C (Left) 081344FL-C (Right) |
| 2. Feed chute | 8. Motor base |
| 3. Lid (Part # 07339PZ11) | 9. Speed Control Dial |
| 4. Stainless steel filter basket (Part # 770275) | 10. Juice cup (Part # 081058PZ13) |
| 5. Pulp Separator (Part # 770294) | 11. Non-slip rubber feet (Part # 19032MZ182) |
| 6. Anti-Drip Juice spout (Part # 081351MZ181) | 12. Removable pulp container (Part # 07337PZ13) |

PERFECT FOR:
Peeled citrus fruits,
hard fruits and
vegetables, leafy
greens and berries.



HOW TO JUICE

This product is for household use only.

GETTING STARTED

- Remove all packing material, any stickers, and the plastic band around the power plug.
- Go to www.prodprotect.com/applica to register your product and visit www.juiceman.com for more recipes, tips and tricks.
- Wash all removable parts as instructed in CARE AND CLEANING

IMPORTANT: Do not rinse or immerse base in water or any other liquid.

- Place base on a dry, level counter and get ready to juice.

PREPARATION



Wash all fruits and vegetables thoroughly.



Remove and discard any outer leaves from non-organic produce and peel away any wax coatings.



Remove the skin, if desired. We recommend removing the skin from citrus fruits as they contain oil that may taste bitter.



Remove all pits and large seeds from fruits.



Trim bruised or discolored sections of fruits and vegetables.



Select fresh, ripened fruits and vegetables for juicing.

ASSEMBLING YOUR COMPACT JUICER

IMPORTANT: Always make sure juicer is unplugged before starting to assemble.



STEP 1: Place the pulp separator on the base.



STEP 2: Place the filter basket into the pulp separator, pressing down to secure it in place.

CAUTION: Handle carefully; the filter basket is sharp!



STEP 3: Slide pulp container into the motor base until it snaps into place.



STEP 4: Place the lid on top of the pulp separator over the filter basket and insert the food pushers into the feed chute.

- There are two food pushers to accommodate a variety of foods. Place the small bean-shaped pusher inside the large pusher when using the large pusher.



STEP 5: Lock the locking latches:

- a. Press down on the lid
- b. Fit the top of each latch into the groove on each side of the lid
- c. Press the bottom of each latch towards motor base until you hear them click into place.



STEP 6: Place the juice cup under the juice spout

IMPORTANT: The juicer will not operate until the locking latches are locked and the pulp container is in place.

USING YOUR COMPACT JUICER

1. Assemble your juicer as instructed in "Assembling Your Compact Juicer"
2. Turn the anti-drip spout clockwise to open the spout.
3. Plug the juicer in and select your speed using the dial
 - a. Speed 1 (low) - best for softer fruits and vegetables
 - b. Speed 2 (high) - best for harder fruits and vegetables
4. Place food in the feed chute and use one of the two pushers to guide food towards the strainer, using gentle pressure.
 - a. The small bean-shaped pusher is best for small fruits and vegetables. Its unique shape guides produce towards the center of the strainer, where it is spinning the fastest, therefore aiding in maximum extraction.
 - b. The large pusher is round to help accommodate most fruits and vegetables. The large pusher also acts as the feed chute when you are using the small pusher.

TIP: Alternate fruits and vegetables to get the most juice and blend the flavors!

IMPORTANT: Never place fingers or hands into the feed chute.

5. When the pulp container is almost full, turn off and unplug the unit. Empty the pulp container and clean the filter basket before you start juicing again.

CAUTION: The filter is very sharp; handle carefully.

6. When you are done juicing, turn the dial to 0 (OFF) and unplug the juicer.
7. Twist the anti-drip spout counterclockwise to close the spout and prevent dripping.
8. Enjoy your juice!

CARING FOR YOUR COMPACT JUICER

*This product contains no user serviceable parts.
Refer service to qualified service personnel.*

CLEANING:

Always clean all parts after every use to prolong the life of the juicer.

1. Turn off the juicer and unplug the unit.
2. Disassemble the juicer to clean parts:



- a. Unlatch the locking latches
- b. Remove the food pusher from the lid
- c. Remove the lid from the pulp separator
- d. Pull pulp container away from the motor base
- e. Grip the indentations on the bottom of the pulp separator and pull up to remove from the motor base. The filter basket will release from the pulp separator.



- f. Carefully lift the filter basket out of the pulp separator, holding the outer edges.
- g. Remove anti-drip spout piece from the juice spout.

3. Wash all removable parts with warm water and dish soap or in the dishwasher, top rack only.

CAUTION: The filter basket is very sharp. Handle carefully.

4. Wipe the base with a damp cloth or sponge; never immerse the juicer base in water or other liquid.

NOTE: Carotenoids that are found in many vegetables, particularly carrots, may cause staining. We recommend soaking any stained parts overnight in one of the following solutions:

- Biodegradable soap in enough warm water to cover juice extractor parts
- 1 cup bleach added to a sink full of warm water
- 1 part warm water to 1 part cider vinegar
- Small box of baking soda in enough warm water to cover juicing parts.

After soaking overnight, lightly scrub with a soft bristle brush and liquid detergent.

STORAGE:

Store your juicer in a clean dry place. Do not wrap the cord tightly around the juicer or put stress on the cord where it connects to the juicer.

TROUBLESHOOTING

Overheat protection system: This juicer contains a PTC overheat protection system. When the appliance is being operated for too long or with too much load, the PTC protector will shut down the power of the appliance to protect the unit. If the power shuts down, unplug for 15 minutes and plug back in for normal operation.

| PROBLEM | POSSIBLE CAUSE | SOLUTION |
|--|---|---|
| Juice extractor is turned on but will not run | Safety lock may not be closed securely | Turn the juicer off and unplug. Make sure everything is properly attached and parts are clean and free of food remnants. |
| Juicer makes loud noises and begins to vibrate. | Soft foods may have clogged the filter | Turn the juicer off and unplug. Remove the filter and clean it with a brush to remove all food particles |
| Motor seems to stall. | Juicing may be too vigorous and/or pulp has built up under the cover. | Turn the juicer off and unplug. Remove the filter and clean with a brush to remove food particles. Clean the lid and continue to juice. |
| Pulp is too wet and not enough juice is being extracted. | May be pushing foods too quickly through the chute. | Use the pusher as a guide; do not use pressure. Turn the juicer off and unplug. Clean the filter and soak in a solution of hot water and lemon juice to remove any excess fiber from the strainer. You may also wash in the dishwasher top rack only. |
| Juice leaks between the pitcher and the lid | Juice pitcher may not be properly placed. Juicing action may be too fast. | Make sure the juice pitcher is flush with the appliance. Slow down the juicing action. |

JUICING TIPS & TRICKS:

-  When juicing carrots, do not overfill the feed chute. Place carrots one at a time and use gentle pressure to guide them through the feed chute.
-  It is not recommended to juice avocados or bananas as these foods naturally do not contain juice. They will produce a paste rather than a juice. However, we recommend adding your fresh juice to a blender with avocados or bananas and ice for a delicious smoothie!
-  For best results, refrigerate fruits and vegetables before juicing.
-  For the most nutritional benefit, enjoy your juice immediately after juicing. If you are taking it to go or storing it for later, we suggest using a vacuum sealed container and storing it in the refrigerator.
-  Do not store juice for more than 24 hours.
-  Tip your juice extractor forward to help any remaining juice drain from the bowl. Simply unplug and carefully tip the juicer forward into your glass.
-  Bunch leafy vegetables into tight rolls before juicing. Juice leafy greens first and follow with additional fruits and vegetables to help push the greens towards the filter.
-  Add lemon juice to freshly extracted juice to help preserve the coloring and bring out the natural flavors of the fruits and vegetables.
-  Add a small spoonful of the pulp to your juice for an addition of fiber.
-  Pour fresh juice into ice cube trays, freeze and use to flavor your water.
-  Freeze the leftover pulp for use in soups and stocks.



Let the juicer run for at least ten seconds before placing any food into the chute.



For easy clean up, line the pulp container with a plastic bag.

JUICE RECIPES



GRAPE PINEAPPLE REFRESH | SERVINGS: 2

INGREDIENTS:

- 1½ cups green grapes
- ¼ Pineapple, rind removed
- ½ lemon, peel removed
- Club Soda

DIRECTIONS:

Juice the fruits through the juicer into a large glass. Stir to blend flavors and divide into two glasses. Add club soda and garnish with two grapes and a lemon peel.



TOMATO VEGGIE JUICE | SERVINGS: 2

INGREDIENTS:

- 4 medium tomatoes, halved
- ½ cucumber
- 1 large stalk celery
- ¼ lime

DIRECTIONS:

Juice fruit and vegetables and stir to blend flavors. Pour into short glasses and garnish with celery.



SUMMER SUNRISE | SERVINGS: 2

INGREDIENTS:

- 1 cup strawberries
- 1 cup raspberries
- ½ pink grapefruit (peel removed)
- 1 large orange (peel removed)

DIRECTIONS:

Juice all fruits into glass and stir to blend flavors.

WARRANTY & CUSTOMER SERVICE INFORMATION

For support or any questions regarding your appliance, call the appropriate 800 number listed within this section. Please **DO NOT** return the product to the place of purchase. Also, please **DO NOT** mail product back to manufacturer, nor bring it to a service center. You may also want to consult our Product Protection Center at www.prodprotect.com/applica.

TWO-YEAR LIMITED WARRANTY

(Applies only in the United States and Canada)

WHAT DOES MY WARRANTY COVER?

- Your warranty covers any defect in material or workmanship provided; however, the liability of Spectrum Brands Inc. will not exceed the purchase price of product.

HOW LONG IS THE WARRANTY PERIOD?

- Your warranty extends two years from the date of original purchase with proof of purchase.

WHAT SUPPORT DOES MY WARRANTY PROVIDE?

- Your warranty provides you with a reasonably similar replacement product that is either new or factory refurbished.

HOW DO YOU GET SUPPORT?

- Save your receipt as proof of date of sale.
- Visit the online service website at www.prodprotect.com/applica, or call toll-free 1-800-231-9786, for general warranty service.
- If you need parts or accessories, please call 1-800-738-0245.

WHAT DOES MY WARRANTY NOT COVER?

- Damage from commercial use
- Damage from misuse, abuse or neglect
- Products that have been modified in any way
- Products used or serviced outside the country of purchase
- Glass parts and other accessory items that are packed with the unit
- Shipping and handling costs associated with the replacement of the unit
- Consequential or incidental damages (Please note, however, that some states do not allow the exclusion or limitation of consequential or incidental damages, so this limitation may not apply to you.)

HOW DOES STATE LAW AFFECT MY WARRANTY?

- This warranty gives you specific legal rights. You may also have other rights that vary from state to state or province to province.

MEET OUR NUTRITION EXPERT



Hi! I'm Sarah Mattison Berndt, Juiceman's primary nutritional guru. It's my mission to make healthy living easy for everyone. Holding a Master's Degree in Nutritional Science from Boston University plus two Bachelor's Degrees from the University of Wisconsin in Dietetics and Zoology, I am happy to be Juiceman's go-to on how-to healthy living!

I am a Registered Dietitian, a certified personal trainer, hold advanced certifications in Adult Weight Management and have received a number of awards for my work in healthy living. I have extensive experience helping others improve their health through my business, and it is my goal to help everyone live their healthiest life with expert nutrition and fitness advice.

Be sure to visit
Juiceman.COM
to find my latest nutritional inspirations, tips & tricks and new recipes for easy, healthy living!

T22-5002618
12802-01 E

® Registered Trademark of
Spectrum Brands, Inc.

© 2015 Spectrum Brands, Inc.
Middleton, WI 53562

Made and Printed in China.