

1. Do not touch hot surfaces. Use handles or knobs.
2. To protect against electrical hazards, do not immerse cord, plug, or the appliance in water or other liquid.
3. Close supervision is necessary when any appliance is used by or near children.
4. Unplug from outlet when not in use and before cleaning.
5. Allow to cool before putting on or taking off parts and before cleaning.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been dropped or damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair or electrical or mechanical adjustment.
7. The use of attachments not recommended by the manufacturer may cause hazards.
8. Keep the cord away from heated surfaces. Do not let the cord hang over the edge of table or counter, as it could be pulled off.
9. Do not use outdoors.
10. Do not place on or near a hot gas or electric burner or in a heated oven.
11. Use extreme caution when moving an appliance containing hot oil or other hot liquids.

READ ALL INSTRUCTIONS BEFORE USING.

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

IMPORTANT SAFETY INSTRUCTIONS



BELGIAN-STYLE ELECTRIC WAFFLE MAKER

WAFLERA ELECTRICA ESTILO BELGA

USE AND CARE BOOK MANUAL DE USO Y MANTENIMIENTO

HOUSEHOLD USE ONLY PARA USO DOMESTICO SOLAMENTE

11. To use, plug cord into electrical outlet. To disconnect, grasp plug and remove from outlet. Do not pull on the cord.
12. Do not use the appliance for other than its intended use.

SAVE THESE INSTRUCTIONS

LINE CORD SAFETY TIPS

1. Never pull or yank on cord or the appliance.
2. To insert plug, grasp it firmly and guide it into outlet.
3. To disconnect appliance, grasp plug and remove it from outlet.
4. Before each use, inspect the line cord for cuts and/or abrasion marks. If any are found, this indicates that the appliance should be serviced and the line cord replaced. Please return it to our Service Department or to an authorized service representative.
5. Never wrap the cord tightly around the appliance, as this could place undue stress on the cord where it enters the appliance and cause it to fray and break.
6. Do not operate appliance if the line cord shows ANY DAMAGE, OR IF APPLIANCE WORKS INTERMITTENTLY OR STOPS WORKING ENTIRELY.

LEA TODAS LAS INSTRUCCIONES ANTES DE USAR.

Cuando use aparatos eléctricos, especialmente cuando hayan niños, medidas básicas de seguridad deben seguirse, incluyendo las siguientes:

1. No toque las superficies que están calientes. Use agarraderas o manecillas.
2. Para protegerse contra peligros eléctricos, no sumerja el cordón, enchufe o el artefacto en agua u otro líquido.
3. Atención supervisión es necesaria cuando cualquier artefacto está siendo usado por, en o cerca de niños.
4. Desenchufe la cuando no la esté usando y antes de limpiarla. Deje que se enfríe antes de poner o sacar alguna parte y antes de limpiarla.
5. No opere ningún artefacto si tiene el cordón o enchufe dañado, después de un mal funcionamiento o se ha caído o dañado de alguna manera. Devuelva el artefacto a un lugar autorizado más cercano para su revisión, reparación o ajuste eléctrico o mecánico.
6. El uso de aditamentos no recomendados por el fabricante pueden ser peligrosos.
7. Mantenga el cordón lejos de superficies calientes. No deje el cordón colgando de la mesa o del mostrador ya que este podría ser halado.
8. No lo use fuera de la casa.
9. No lo coloque en o cerca de un calentador a gas o eléctrico o en un horno caliente.

IMPORTANTES INSTRUCCIONES DE SEGURIDAD

GARANTIA LIMITADA POR UN AÑO

Dentro de un año de garantía, nosotros le reemplazaremos este artefacto sin costo alguno por defectos en material o manufactura. Para reemplazo, envíe el artefacto con evidencia de compra. Esta garantía es nula si el artefacto se ha caído, abusado, alterado o mal usado en cualquier forma.

GUARDE PARA REFERENCIA

1. Nunca hale o tire del cordón o del artefacto.
2. Para introducir el enchufe, sujételo firmemente y guíelo hacia el tomacorriente.
3. Para desconectar el artefacto, sujete el enchufe y retírelo del tomacorriente.
4. Antes de cada uso, inspeccione el cordón si tiene cortes y/o raspaduras. Si algo fuera encontrado, esto indica que el artefacto deberá ser revisado y el cordón deberá ser reemplazado. Por favor, devuélvalo a nuestro Departamento de Servicio o a un representante de servicio autorizado.
5. Nunca enrolle el cordón ajustadamente alrededor del artefacto, ya que esto podría causar una presión excesiva en el cordón donde éste entra al artefacto y causar desgaste y rotura.
6. No haga funcionar el artefacto si el cordón muestra cualquier daño, o si el artefacto funciona intermitentemente o deja de funcionar completamente.

CONSERVE ESTAS INSTRUCCIONES

10. Tenga mucho cuidado cuando mueva un artefacto contenido aceite caliente u otros líquidos calientes.
11. Para usarla, enchuféla en un tomacorriente eléctrico. Para desconectarla, empúñe el enchufe y retírelo del tomacorriente. No tire del cordón.
12. No use este artefacto para otros fines que no sea los especificados.

ONE YEAR LIMITED WARRANTY

Within one year of purchase, we will replace this appliance free if defective in material or workmanship. For replacement, return appliance with evidence of purchase. This warranty is voided if appliance has been dropped, abused, altered, misused or tampered with in any way.

SAVE THIS FOR YOUR RECORDS